

# ROSEMOUNT 8700 SERIES CONFIGURATION DATA SHEET

All sections up to C1 Note are required on this form.  
 ★ = Default Value

Select only one of the items provided  
 One or more of the listed items can be selected

Customer Information	
Customer: _____	Contact Name: _____
P.O./Reference No.: _____	Fax No./Email: _____
Phone No.: _____	P.O. Line Item: _____
Quote No.: _____	Model No.: _____
Customer Sign off: _____	

Instrument Tag	
Name Plate: _____ (1 line, 21 characters max)	Wire-On: _____ (5 lines, 17 characters/line)
	_____
	_____
	_____
	_____

Meter			
Model Type:	<input type="radio"/> Sensor	<input type="radio"/> Magmeter System (Sensor and Transmitter)	<input type="radio"/> Transmitter
Transmitter Type:	<input type="radio"/> Integral Mount	<input type="radio"/> Remote Mount	

Fluid Selection	
Fluid:	Name: _____
	Density or Specific Gravity <sup>(1)</sup> : _____
	Conductivity: _____

(1) Required for Mass Units only.

Process Information <sup>(1)</sup>					
	Units	Minimum	Normal	Maximum	Design
Flow Rate:					
Pressure:					
Process Temp:					

(1) Gray boxes are required values.

Process Variable Configuration HART Output Only			
	4 mA LRV (0.0★)	20 mA URV (30★)	Unit of Measure (ft/sec★)
Flow:			

**C1 NOTE**

The following sections are required only if C1 option is selected.

<b>Basic Configuration</b>	
Damping = 2.0 seconds* _____	
Sensor Size = 3-in. * _____	3 to 36-in. (8712H) / 0.10 to 80-in. (All others)
<b>Special Units (HART only)</b>	
For a list of all standard configurable units, consult the appropriate product manual available on <a href="http://www.emersonprocess.com/rosemount">www.emersonprocess.com/rosemount</a> .	
Volume Units: _____ (4 characters)	
Base Units:	<input type="radio"/> Gallons <input type="radio"/> Cubic Meters <input type="radio"/> Barrels <input type="radio"/> Short Ton <input type="radio"/> Kilogram <input type="radio"/> Liters <input type="radio"/> Cubic Centimeters <input type="radio"/> Barrels (beer) <input type="radio"/> Pound <input type="radio"/> Imperial Gallon <input type="radio"/> Feet <input type="radio"/> Cubic Feet <input type="radio"/> Metric Ton <input type="radio"/> Meters
Conversion Factors: _____ where one special unit = Conversion Factor × Base Unit	
Time Base:	<input type="radio"/> Seconds <input type="radio"/> Minutes <input type="radio"/> Hours <input type="radio"/> Days
Rate Units: _____ (4 characters)	
<b>HART/Transmitter Information</b>	
Write Protect	<input type="radio"/> Off* <input type="radio"/> On
Alarm Option	<input type="radio"/> High* <input type="radio"/> Low (8732E/8712E only)
Alarm Standard	<input type="radio"/> Rosemount* <input type="radio"/> Namur
Descriptor _____ (16 characters maximum) Date (day/month/year): ____/____/____	
Message _____ (32 characters maximum)	
<input type="radio"/> 4-20 mA, scaled pulse, and auxiliary output with simultaneous digital signal based on HART® protocol* <input type="radio"/> Burst mode of HART digital process variable	
Burst mode output options:	
<input type="radio"/> Primary variable in engineering units. <input type="radio"/> Primary variable in percent of range. <input type="radio"/> All dynamic variables in engineering units. <input type="radio"/> All dynamic variables in engineering units and the primary variable mA value.	
<input type="radio"/> Multidrop Communications <sup>(1)</sup>	
Choose transmitter address (1-15) <sup>(2)</sup> _____	

(1) This option fixes the transmitter's analog output at 4 mA.

(2) Default transmitter address is 1 if multidrop communication is selected.

# CONFIGURATION DATA SHEET • ROSEMOUNT 8700 SERIES

Sensor Information (Data Only - Does Not Affect Transmitter Output)			
Sensor Tag No. (Software) _____ (8 characters HART; 32 characters Fieldbus)			
Sensor Serial No. _____ (7 characters maximum)			
Sensor Calibration No. _____ 16 Digits from sensor 1000005010000000*			
SST Sensor Tag No. _____			
Enter either the Rosemount sensor model number or select one option from each of the following groups of options:			
Sensor Model No. _____			
Electrode Material <input type="radio"/> 316 SST* <input type="radio"/> Titanium <input type="radio"/> Nickel Alloy-276	<input type="radio"/> Tantalum <input type="radio"/> Platinum-Iridium <input type="radio"/> Special	Electrode Type <input type="radio"/> Standard* <input type="radio"/> Bullet	<input type="radio"/> Standard, plus Grounding <input type="radio"/> Special
Flange Material <input type="radio"/> Carbon Steel* <input type="radio"/> 316 SST	<input type="radio"/> 304 SST <input type="radio"/> Wafer	Liner Material <input type="radio"/> PTFE* <input type="radio"/> ETFE <input type="radio"/> Polyurethane	<input type="radio"/> Neoprene <input type="radio"/> Linatex Rubber <input type="radio"/> Special
Advanced Configuration Options (Not Required for Typical Start-up)			
Pulse Scaling. (Not available in FOUNDATION™ fieldbus)  <input type="radio"/> 0.03 ft* <input type="radio"/> 1 Pulse = _____ units  Pulse Width: _____ 0.5 ms*	Operation Mode:  <input type="radio"/> Normal*  <input type="radio"/> Filter	Signal Processing:  <input type="radio"/> Off* <input type="radio"/> On  _____ 90* No. Samples _____ 2* Max.% Limit% _____ 2* Time Limit Sec	
Low Flow Cutoff: _____ 0.04 ft/sec*	Coil Pulse Mode (Not available with 8712H)  <input type="radio"/> 5 Hz* <input type="radio"/> 37.5 Hz		
Local Display Language (8732E only) <input type="radio"/> English* <input type="radio"/> Spanish <input type="radio"/> French <input type="radio"/> German <input type="radio"/> Portuguese			
Flow Direction Reverse Flow <input type="radio"/> Enable <input type="radio"/> Disable*			
Flowrate Display (Not available in FOUNDATION fieldbus) <input type="radio"/> Flow and % Span* <input type="radio"/> Flow and Net Total <input type="radio"/> Flow and Gross Total <input type="radio"/> % Span and Net Total <input type="radio"/> % Span and Gross Total			
Totalizer Display (Not available in FOUNDATION fieldbus) <input type="radio"/> Net and Gross* <input type="radio"/> Forward and Reverse			
Analog Loop Power (HART only) <input type="radio"/> Internal* <input type="radio"/> External (8732E/8712E only)			
Pulse Loop Power (8732E only) <input type="radio"/> Internal* <input type="radio"/> External*			
Simulate (FOUNDATION fieldbus only) <input type="radio"/> Off* <input type="radio"/> On*			

<b>Standard Diagnostics Information</b>			
Empty Pipe Trigger Level _____ 100* (8732E/8712E only) <input type="radio"/> Enable*      Empty Pipe Counts _____ 5* (8732E/8712E only) <input type="radio"/> Disable			
Electronics Temperature (8732E/8712E only) <input type="radio"/> Enable* <input type="radio"/> Disable			
<b>Advanced Diagnostics Information (Requires DA1/D01 Option) (8732E/8712E only)</b>			
High Process Noise <input type="radio"/> Enable* <input type="radio"/> Disable	Grounding/Wiring Faults <input type="radio"/> Enable* <input type="radio"/> Disable	Note If DA1/D01 is selected in the model code, Empty Pipe and Electronics Temp Diagnostics will also be enabled.	
Electrode Coating Detection (HART and Modbus® only) (8732E Only) <input type="radio"/> Enable*      Electrode Coating Level 1 _____ 1000kOhm* <input type="radio"/> Disable      Electrode Coating Level 2 _____ 2000kOhm*			
<b>8714i Meter Verification Diagnostics (Requires DA2/D02 Option) (8732E HART and Modbus only, 8712 HART only)</b>			
Test Criteria Empty Pipe: _____ 5%* Flowing Full: _____ 5%* Full, No Flow: _____ 5%*		Note The Test Criteria value sets the pass fail value for the meter calibration verification check. This value must be an integer value between 1 and 10%.	
<b>Continuous Meter Verification (Requires DA2/D02 Option) (8732E HART and Modbus only)</b>			
Test Criteria _____ 5%*			
Transmitter <input type="radio"/> Enable* <input type="radio"/> Disable	Coil <input type="radio"/> Enable* <input type="radio"/> Disable	Electrode Resistance <input type="radio"/> Enable <input type="radio"/> Disable*	Analog Signal <input type="radio"/> Enable* <input type="radio"/> Disable
<b>Discrete Input/Discrete Output Information (Requires AX Option) (8732E/8712E only)</b>			
DI/DO Channel <input type="radio"/> Input* <input type="radio"/> Output <input type="radio"/> Disable	Discrete Input Configuration <input type="radio"/> Positive Zero Return (PZR)* <input type="radio"/> Totalizer Reset	DO Channel 2 <input type="radio"/> Enable* <input type="radio"/> Disable	
Discrete Output Configuration <input type="checkbox"/> Reverse Flow <input type="checkbox"/> Flow Limit 1 <input type="checkbox"/> Zero Flow* <input type="checkbox"/> Flow Limit 2 <input type="checkbox"/> Transmitter Fault (Alarm) <input type="checkbox"/> Diagnostic Status Alert <input type="checkbox"/> Empty Pipe <input type="checkbox"/> Totalizer Limit 1		Discrete Output Configuration <input type="checkbox"/> Reverse Flow <input type="checkbox"/> Flow Limit 1 <input type="checkbox"/> Zero Flow* <input type="checkbox"/> Flow Limit 2 <input type="checkbox"/> Transmitter Fault (Alarm) <input type="checkbox"/> Diagnostic Status Alert <input type="checkbox"/> Empty Pipe <input type="checkbox"/> Totalizer Limit 1	
<b>Flow and Totalizer Alert Configuration (8732E/8712E HART only)</b>			
Flow Limit 1 Configuration Control 1 <input type="radio"/> ON <input type="radio"/> OFF* Mode 1 <input type="radio"/> > High Limit <input type="radio"/> < Low Limit <input type="radio"/> In Range <input type="radio"/> Out of Range High Limit 1: _____ High Limit 1: _____ Flow Limit Hysteresis: _____	Flow Limit 2 Configuration Control 2 <input type="radio"/> ON <input type="radio"/> OFF* Mode 2 <input type="radio"/> > High Limit <input type="radio"/> < Low Limit <input type="radio"/> In Range <input type="radio"/> Out of Range High Limit 2: _____ High Limit 2: _____	Totalizer Limit Configuration Control <input type="radio"/> ON <input type="radio"/> OFF* Mode <input type="radio"/> > High Limit <input type="radio"/> < Low Limit <input type="radio"/> In Range <input type="radio"/> Out of Range High Limit: _____ High Limit: _____ Totalizer Limit Hysteresis: _____	

# CONFIGURATION DATA SHEET • ROSEMOUNT 8700 SERIES

## Diagnostic Status Alert (8732E/8712E HART only)

- |  |   |   |
|--|---|---|
| <input type="checkbox"/> Electronics Failure           | <input type="checkbox"/> Coil Open Circuit                        | <input type="checkbox"/> Continuous Meter Verification (8732E only) |
| <input type="checkbox"/> Electronics Temp Out of Range | <input type="checkbox"/> Coil Over Current (8732E only)           | <input type="checkbox"/> Grounding/Wiring Fault                     |
| <input type="checkbox"/> Empty Pipe                    | <input type="checkbox"/> Coil Power Limit (8732E only)            | <input type="checkbox"/> High Process Noise                         |
| <input type="checkbox"/> Reverse Flow                  | <input type="checkbox"/> Sensor Electrode Saturation (8732E only) | <input type="checkbox"/> Electrode Coating Level 1 (8732E only)     |
| *Select as many options as needed for the application  |   | <input type="checkbox"/> Electrode Coating Level 2 (8732E only)     |

## Diagnostic Analog Alarm Configuration (8732E only)

Analog Output to Alarm

- |   |  |
|---|--|
| <input type="checkbox"/> Empty Pipe                           | <input type="checkbox"/> Totalizer Limit Alert         |
| <input type="checkbox"/> Reverse Flow                         | <input type="checkbox"/> Flow Limit 1 Alert            |
| <input type="checkbox"/> Grounding and Wiring                 | <input type="checkbox"/> Flow Limit 2 Alert            |
| <input type="checkbox"/> High Process Noise                   | <input type="checkbox"/> Continuous Meter Verification |
| <input type="checkbox"/> Electronics Temperature Out of Range | <input type="checkbox"/> Electrode Coating Level 2     |

## Modbus RS-485 Configuration (\*default)

Soft Tag \_\_\_\_\_ (8 characters)

Address \_\_\_\_\_ (1-247; default = 1)

### Format Code

- | Format Code             | Byte Transmission Order | Description                                       |
|-------------------------|-------------------------|---|
| <input type="radio"/> 0 | [AB] [CD]               | Straight word order, most significant byte first  |
| <input type="radio"/> 1 | [CD] [AB]               | Inverse word order, most significant byte first   |
| <input type="radio"/> 2 | [DC] [BA]               | Inverse word order, least significant byte first  |
| <input type="radio"/> 3 | [BA] [DC]               | Straight word order, least significant byte first |

### Baud Rate

- |                              |                             |                             |                              |
|------------------------------|-----------------------------|-----------------------------|------------------------------|
| <input type="radio"/> 1200   | <input type="radio"/> 2400  | <input type="radio"/> 4800  | <input type="radio"/> 9600   |
| <input type="radio"/> 19200* | <input type="radio"/> 38400 | <input type="radio"/> 57600 | <input type="radio"/> 115200 |

### Parity

- |                             |                           |                                 |
|-----------------------------|---------------------------|---------------------------------|
| <input type="radio"/> Even* | <input type="radio"/> Odd | <input type="radio"/> No Parity |
|-----------------------------|---------------------------|---------------------------------|

### Stop Bits

- |                              |                             |
|------------------------------|-----------------------------|
| <input type="radio"/> 1 Bit* | <input type="radio"/> 2 Bit |
|------------------------------|-----------------------------|

The Emerson logo is a trademark and service mark of Emerson Electric Co.  
 Brand logotype are registered trademarks of one of the Emerson family of companies.  
 All other marks are the property of their respective owners.  
 © 2024 Emerson Electric Co.  
 All rights reserved.

For more information, visit  
[Emerson.com/RosemountMagneticFlow](https://www.emerson.com/RosemountMagneticFlow)

00806-0100-4727, Rev UE

